

ATTENTION!

**FACTORY TESTED
ONLY HOMEOWNER SHOULD REMOVE LABEL**

Once installed, remove label and operator lock (see below). Blinds should remain in tight stack at top during transit, storage, door assembly and installation.

CAUTION

Excessive force or abrupt operation can be harmful to blind slats and cords

blink
BLINDS + GLASS

An **DDL** brand

Operator
Lock



Step 1

Peel



Stretch Release

Step 2

ATTENTION HOMEOWNER

CARE & USE INSTRUCTIONS RAISE & LOWER BLINDS

To ensure years of smooth, easy operation of your blinds, follow these simple instructions:

- Slide the operator up or down to position the blind to the desired height. Some blinds have a separate tilt control; slide it up or down to tilt the blinds to the desired angle.
- For ease of operation, ensure the glass surface is clean. Dirty glass can impede operator movement, thus requiring more force to operate the blinds.
- The blind raises and lowers through use of magnets. If the operator comes loose from the glass so that you are unable to operate the blind, it means the operator magnets have become disengaged. If your operator becomes disengaged, it's easy to correct - just slide the operator all the way to the top of the unit to re-engage it (see diagrams).

1. Slide the lower operator upward until you hear/ feel one click (*diagram A*).
2. Continue sliding the operator up until you hear/feel a second click (*diagram B*).

Important: You must slide the operator to the very top (two clicks) to engage the magnets.

- If blind bottom rail becomes out-of-level, raise the blinds to the fully open position and then fully lower them. Repeat if necessary. The blinds will adjust themselves back to level.

